

Compatible Camera Models of Godox Camera Flashes and Macro Flashes

Compatible Canon Camera Models

Godox Camera Flashes: V1ProC、V1C、V860IIIC、V350C、TT685IIC、TT685C、TT350C、V100 C

Godox Macro Flashes: MF-R76C

Compatible Nikon Camera Models

Godox Camera Flashes: V1ProN, V1N, V860IIIN, V350N, TT685IIN, TT685N, TT350N, V100

Godox Macro Flashes: MF-R

| Mode | Type | Camera Flashes | | | | | | 2.4G Transmitter & Receiver Flash Units | | | | | | Auto Focus Assist Beam | Note | |
|-------|--------------------|--------------------|-------------------|-------------|--------------------|-------------------|-------------|---|--------------------|-------------------|-----|--------------------|-------------------|------------------------|-------------|---|
| | | TTL Flash | | | M Flash | | | Multi Flash | TTL Flash | | | M Flash | | | Multi Flash | |
| | | Front-curtain Sync | Rear-curtain Sync | HSS | Front-curtain Sync | Rear-curtain Sync | HSS | | Front-curtain Sync | Rear-curtain Sync | HSS | Front-curtain Sync | Rear-curtain Sync | HSS | | |
| D800 | SLR Cameras | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| D750 | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| D700 | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| D610 | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| D500 | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| D200 | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| D300S | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| D5 | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| D4 | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| D810 | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| D780 | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| D850 | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| D5300 | | ✓ | ✓ | Unavailable | ✓ | ✓ | Unavailable | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| D5200 | | ✓ | ✓ | | ✓ | ✓ | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| D5100 | | ✓ | ✓ | | ✓ | ✓ | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| D5000 | | ✓ | ✓ | | ✓ | ✓ | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| D3300 | | ✓ | ✓ | | ✓ | ✓ | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| D3200 | | ✓ | ✓ | | ✓ | ✓ | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| D3100 | | ✓ | ✓ | | ✓ | ✓ | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| D60 | | ✓ | ✓ | | ✓ | ✓ | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| D7100 | | ✓ | ✓ | | ✓ | ✓ | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| D7500 | | ✓ | ✓ | | ✓ | ✓ | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| Z6 | Mirrorless Cameras | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| Z7II | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| Z8 | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| ZFC | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| Z9 | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| | | | | | | | | | | | | | | | Unavailable | |

Compatible FUJIFILM Camera Models

Godox Camera Flashes: V1ProE, V1E, V860IIIE, V350E, TT685IIIE, TT685E, TT350E, V100E

Compatible Sony Camera Models A

Godox Camera Flashes: TT350S、V350S

| Mode | Type | 机顶闪光灯Camera Flashes | | | | | | 2.4G Transmitter & Receiver Flash Units | | | | | | Auto Focus Assist Beam | Note | | |
|----------|-------------------------|---------------------|-------------------|-----|--------------------|-------------------|-----|---|--------------------|-------------------|-----|--------------------|-------------------|------------------------|------|-------------|---|
| | | TTL Flash | | | M Flash | | | Multi Flash | TTL Flash | | | M Flash | | | | | |
| | | Front-curtain Sync | Rear-curtain Sync | HSS | Front-curtain Sync | Rear-curtain Sync | HSS | | Front-curtain Sync | Rear-curtain Sync | HSS | Front-curtain Sync | Rear-curtain Sync | HSS | | | |
| a77II | SLR Cameras | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | |
| a99 | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | |
| a77 | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | |
| a350 | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | |
| DSC-RX10 | Cameras with Fixed Lens | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | Unavailable | |
| a6000 | Mirrorless Cameras | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | | |
| a9 | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| a7R | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | | |
| a7RII | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | | |
| a7M3 | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | | |
| a7RIII | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | | |
| a7RIV | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | | |
| a7MIV | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | | |
| a7RS5 | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | | |
| a6400 | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | | |
| a6500 | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | | |
| ZV-E10 | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | | |

Compatible Sony Camera Models B

Godox Camera Flashes: MF-R76S/TT685S/TT685IIIS/V860IIS/V860IIIS/V1S/V1ProS/V100 S

Compatible Olympus and Panasonic Camera Models

odox Camera Flashes: V1ProO, V1O, V860IIIO, V3500, TT685IIIO, TT685O, TT3500, V1000

Compatible Pentax Camera Models

odox Camera Flashes: V1P, V860IIIP, TT685IIP, TT350P

| Mode | Type | Camera Flashes | | | | | | | 2.4G Transmitter & Receiver Flash Units | | | | | | | Auto Focus Assist Beam | Note | | |
|-------|--------|--------------------|-------------------|-----|--------------------|-------------------|-----|-------------|---|-------------------|-----|--------------------|-------------------|-----|-------------|------------------------|------|--|--|
| | | TTL Flash | | | M Flash | | | Multi Flash | TTL Flash | | | M Flash | | | Multi Flash | | | | |
| | | Front-curtain Sync | Rear-curtain Sync | HSS | Front-curtain Sync | Rear-curtain Sync | HSS | | Front-curtain Sync | Rear-curtain Sync | HSS | Front-curtain Sync | Rear-curtain Sync | HSS | | | | | |
| K-50 | Pentax | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | | |
| K-S2 | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | | |
| K-1 | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | | |
| K-3II | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | | |
| 645Z | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | | |
| KP | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | | |
| K-70 | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | | |
| | | | | | | | | Unavailable | | | | Unavailable | | | | | | | |

This table only lists the tested camera models, not all cameras. For the compatibility of other camera models, a self-test is recommended.

Rights to modify this table are retained